


LMOSTBMPL3115A2 Quick Start Guide

1 Unpack the Kit

- Unpack the board. Verify package contents according to the kit website: freescale.com/sensortoolbox.
- Assemble the hardware by connecting the development board to the USB interface board. Both of these board types have a small arrow to indicate where to connect. See the image below. More information can be found at freescale.com/sensortoolbox.



2 Download Latest Software

- At freescale.com/sensortoolbox download the latest software version.
- All Sensor Toolbox kits use the same software and driver, so the install only needs to be done once. Follow the on-screen instructions to install the communication driver for the tool. Check back occasionally for software updates.

3 Turn It On


- Plug in the USB and turn the board on using the power switch.
- Run the Sensor Toolbox link on your desktop.
- Explore other sensor kits at freescale.com/sensortoolbox.






Connector for All
Sensor Toolbox Pressure
Sensor Development Boards

Sensor
Interface
Board




MPL3115A2
3 x 5 x 1.1 mm
LGA Package



KITSTBMPL3115A2
Development Board

LFSTBUSB
Communication Board



Power
Switch

USB Mini-b
Connector

Learn More at freescale.com/sensortoolbox

Freescale and the Freescale logo are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. Xtrinsic is a trademark of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.
© 2011 Freescale Semiconductor, Inc.



Doc Number: DEMOMPL3115A2QSG / REV 0
Agile Number: 926-78612 / REV A